



TABLE OF CONTENTS

Section 1 - Getting Started

VesselView 7 Overview.....	2	Obtaining the Latest Software.....	6
Front Controls.....	2	Upgrading VesselView.....	7
Front Control Operations.....	2	Touch-Screen Calibration.....	8
Rear Panel.....	3	Creating Screen Captures.....	8
VesselView 7 Screen Display Locations and Descriptions.....	3	Non-Mercury Marine Menus.....	10
Safe Boating Screen.....	5	Maintenance.....	11
How to Update Your VesselView 7 Software.....	5	Display Screen Cleaning.....	11
Backup Your Waypoints, Routes, and Tracks.....	5	Media Port Cleaning.....	11

Section 2 - Initial Screens and Setup Wizard

VesselView 7 Startup Warning Screen.....	14	Data Source Setup.....	22
Splash Screen.....	14	Display Screens.....	24
Setup Wizard.....	14	Startup.....	24
Import Configuration.....	15	Engine Off, Ignition On.....	24
Engine Setup.....	15	Engine Running at Idle.....	24
Display Setup.....	17	System Scan - Scan Report.....	25
Device Setup.....	18	Communication Errors.....	26
Units Setup.....	18	Engine Fault.....	26
Tank Configuration.....	18	Fault Navigation.....	26
Speed Setup.....	21	Engine Scheduled Maintenance.....	27
Finishing Setup Wizard.....	21		

Section 3 - Screen Overview and Operation

System Status Field Functionality.....	30	ECO RPM and Trim Targets.....	40
Enlarging Data Boxes.....	31	Target Colors.....	41
Auto Cycle.....	31	ECO Navigation.....	41
Scroller Bar Functionality.....	32	ECO Refresh.....	42
Scroller Bar Activation and Navigation.....	32	Minimize.....	42
User-Selected Data Area.....	33	Exit ECO.....	43
Scroller Bar Icons.....	33	Changing ECO Targets.....	43
X-Pand.....	33	Changing Target Values.....	44
Temperatures.....	34	Smart Tow Mode.....	44
Pressure.....	34	Smart Tow.....	44
Voltages.....	34	Features.....	44
Fuel.....	35	Enabling Smart Tow.....	46
Tanks.....	35	Smart Tow Targets.....	46
Advanced.....	35	Save.....	47
Performance.....	36	Disabling Smart Tow.....	47
Trim and Tabs.....	36	Cruise Control Mode.....	47
Trip Log.....	36	Cruise Control.....	47
Navigation.....	37	Cruise Control Data Area.....	48
Generator.....	37	Constant Data Area Change.....	48
ECO.....	37	Cruise—User-Selected Data Area.....	49
Autopilot.....	38	Cruise Navigation.....	49
Cruise.....	38	Autopilot Mode.....	50
Troll.....	38	Autopilot Screen Overview.....	50
Smart Tow.....	39	Autopilot Screens Navigation.....	50
Settings.....	39	Minimize Autopilot.....	51
Economy Mode.....	40	Troll Control Mode.....	51
ECO Mode.....	40	Troll Control.....	51
ECO Minimum and Maximum Values.....	40		

Troll Control Data Area.....	52
Constant Data Field Change.....	52

Troll—User-Selected Data Area.....	52
Troll Navigation.....	53

Section 4 - Setup and Calibrations

Settings Menu Navigation.....	56	Engine Model Settings.....	72
Navigation to the Settings Menu.....	56	Limits Settings.....	73
System Settings.....	56	Supported Data Settings.....	74
Navigation.....	56	ECO Mode Settings.....	75
Language Settings.....	57	Cruise/SmartTow Settings.....	75
About Setting.....	57	Trim Settings.....	75
Helm and Device Settings.....	58	Trim Calibration.....	76
Setup Wizard Setting.....	59	EasyLink Settings.....	77
Restore Defaults Setting.....	59	Navigation.....	77
Network Settings.....	60	Preferences Settings.....	79
Simulate Setting.....	61	Navigation.....	79
Time Settings.....	61	Buzzer Settings.....	80
Vessel Settings.....	62	Backlight Settings.....	80
Navigation.....	62	Scroller Bar Settings.....	81
Tabs Settings.....	62	Data Boxes Settings.....	82
Tank Settings.....	63	Popups Settings.....	83
Tank Calibration.....	64	Auto-Cycle Interval Settings.....	85
Reverse calibration.....	64	Alarm Settings.....	85
Speed Settings.....	64	Navigation.....	85
Steering Settings.....	67	Alarms Settings.....	85
Camera Settings.....	69	Personality File Settings.....	86
Sea Temp Setting.....	69	Navigation.....	86
Depth Offset Setting.....	70	Settings.....	87
Engines Settings.....	71	Export Settings.....	87
Navigation.....	71	Import Settings.....	88
Engines Shown Settings.....	71	Restore Settings.....	89

Section 5 - Warning Alarms

Warnings—Faults and Alarms.....	92	Depth Alarm.....	94
Fuel Critical Alarm.....	93		

Section 1 - Getting Started

1

Table of Contents

VesselView 7 Overview.....	2	Obtaining the Latest Software	6
Front Controls	2	Upgrading VesselView	7
Front Control Operations	2	Touch-Screen Calibration	8
Rear Panel	3	Creating Screen Captures.....	8
VesselView 7 Screen Display Locations and Descriptions.....	3	Non-Mercury Marine Menus.....	10
Safe Boating Screen.....	5	Maintenance.....	11
How to Update Your VesselView 7 Software.....	5	Display Screen Cleaning	11
Backup Your Waypoints, Routes, and Tracks	5	Media Port Cleaning	11

VesselView 7 Overview

IMPORTANT: VesselView is a multifunction display (MFD) that is compatible with products manufactured by Mercury Marine Outboards, Mercury MerCruiser, and Mercury Diesel. Some of the functions explained in this manual will be disabled depending on the power package it is connected to.


VesselView 7 is a comprehensive boat information center that can display information for up to four gasoline or diesel engines. It continuously monitors and reports operating data including detailed information such as water temperature and depth, trim status, boat speed and steering angle, and the status of fuel, oil, water, and waste tanks.

VesselView can be fully integrated with a vessel's global positioning system (GPS) or other NMEA-compatible devices to provide up-to-the-minute navigation, speed, and fuel-to-destination information.

VesselView is a display extension for autopilot and joystick operations. All functionality of these piloting features are controlled through Mercury Marine's autopilot control area network (CAN) pad. VesselView will show if a mode of control is active or in standby; pop-ups will appear as the vessel arrives at waypoints, prompting response to turns. Additional display text can be used to adjust the engines and drives to achieve maximum efficiency.

VesselView is equipped with a micro SD card port that allows the import or export of the vessel personality configuration. It can also be used by the owner to upgrade to the latest software version. When more than one VesselView is used, either as a triple-engine or quad-engine application, or a second helm, the same micro SD card can be used to download those configurations to each VesselView unit.

Front Controls



60142

Front Control Operations

Touch screen: The screen on VesselView 7 has numerous districts that are touch sensitive and operated with a touch, or with a vertical or horizontal swipe.

MARK-MENU: The MARK-MENU has two functions and is dependent on which screen mode is active. Press the MARK-MENU button while the chartplotter is visible to access waypoints and other functions. Press the button while SmartCraft information is visible to open the scroller bar.

STBY-AUTO: Allows the operator to suspend (standby) or engage Navico® systems operation.

Exit: Closes a menu and removes the cursor from the screen.

Rotary knob: Used for maneuvering in menus, zooming in charts, and can be pressed to enter a selection.


GO TO-PAGES: A short press displays the home panel pages and can be pressed multiple times to toggle through the home page menus. A long press displays the Go To menu options.

IN OUT-MOB: Zoom buttons for various NMEA backbone components. Pushing the IN and OUT buttons at the same time will mark the position of the vessel with a man overboard (MOB) icon.

Power–Standby–Brightness: Press once to access the standby mode, change the backlighting of the unit, or go to night mode.

Card reader: Allows VesselView software to be upgraded, to have navigation charts uploaded, and waypoints and settings to be saved.


Rear Panel




Item	Function	Description
a	SmartCraft	Connects to the SmartCraft network
b	Power	Power input
c	Video in	Provides two composite video inputs
d	SIMNET/NMEA 2K	Connects to NMEA 2K network
e	Network	Ethernet network ports

VesselView 7 Screen Display Locations and Descriptions

VesselView has multiple fields that display specific engine information and active modes. To activate and display information through the touch sensitive screen, the operator can use the following gestures.






60140

Touch, swipe, and display locations

1. Application swap: Touching this area of the screen will toggle between a Mercury application screen and the last Navico® screen.
2. Volts or depth: This data field is user definable. A list of all available display content is available in the **Settings** menu.
3. The steering angle will be available if the installed sensor is connected to the SmartCraft control area network. Steering angle is turned off by default, but can be manually turned on in the **Settings** menu.
4. Speed: Displays the speed of the vessel. If a speed source is not available, the display will show dashes. The display will show the speed value, the speed source—paddle wheel, pitot, or GPS, and the units of measurement—MPH is the default. A speed value greater than two digits will be shown in a smaller font.
5. RPM: Displays a moving bar representing the engine RPM. A dual-engine application will show two separate moving bars, a triple-engine application will show three, a quad-engine application will show four.
6. Fuel: This data field displays total fuel onboard.
 - Displays total fuel only. Individual fuel data will be located in the selected data area under fuel management.
7. Menu: Touch this area to show the scroller bar. The scroller bar allows the operator to select different Mercury application screens to open in the user selected data area. Use left or right swipes in the scroller bar to highlight scroller bar items.
8. Gear position: DTS products will display all gear positions for each engine. The positions are defined as **F**—forward, **N**—neutral, and **R**—reverse. Non-DTS products will show **N**—neutral and **G**—in gear.
9. Trim: This data field is user definable. Displays trim for up to four engines. Trim pop-up is available in the selected data area. Trim pop-up can be turned off or on in the **Settings** menu.
10. Selected data icon: Displays an icon representing the data currently being displayed in the selected data area of the screen. It will also display the previously selected data icon if there is currently no selected data being displayed. Touch the MENU arrow button to open the scroller bar. The user can select an icon in the scroller bar and the selected data will then be displayed.
11. System status: Displays the current active mode and warnings.
12. Selected data area: Displays all selected data, including initial start up scan progress, good stewardship messages, maintenance schedules, and warnings. Additional data can be accessed by touching icons in the footer bar or by swiping the data area up, down, left, or right.
13. The auto cycle icon will display all of the data screens associated with a menu selection. The display will cycle through, in sequence, at a user selected time interval.
14. The **X** icon will close, or exit, the current data selection.

Safe Boating Screen

Each time that VesselView is powered on, after a complete shutdown of 30 seconds or more, a screen containing advisories regarding boating safety is displayed to the operator. Touch the Accept button to continue.



60144


How to Update Your VesselView 7 Software

The following instructions explain how to upgrade the VesselView 7 software. Internet access is required along with a communication port used to transfer the file to a FAT or FAT 32 micro SD card.

Backup Your Waypoints, Routes, and Tracks

Although waypoints, routes, and tracks should not be affected, it is recommended that these are backed up before starting the upgrade. The backup process copies all waypoints, routes, and tracks to a micro SD card. The card can be the same one that has the upgrade files. Depending on the amount of information you will backup, the card must have the capacity to store it.


1. Turn the ignition key on and verify that the VesselView is on.
2. Insert the micro SD card into the card reader port all the way until it clicks and stays in place.
3. Press the PAGES button below the rotary knob.
4. Select Tools; then select Files.
5. Select Waypoints, Routes, and Tracks.



52711

6. Select the desired file format and then press Export.


7. Select the micro SD card as the destination and select OK.



8. Name the backup file using the on-screen keyboard and then press Enter.

Obtaining the Latest Software

1. The latest software for the display is available online for general download at Mercury's website; <https://www.mercurymarine.com>. To understand what software version is in VesselView, power up VesselView. While the system boots up, the screen will show the software version in the lower right-hand corner. If VesselView is already powered up, select Settings>System>About to see the current operating version of VesselView software.



55829



56944

2. Select the VesselView 7 product and click on Download VesselView 7 Update.
3. Depending on your computer's security settings, a security warning may appear. Click Allow to continue.
4. Create a folder on your hard drive and save the file in this folder.
5. If you are asked to SAVE or RUN, select SAVE and save to your hard drive.

NOTE: The file is typically 70–100 MB in size.

IMPORTANT: Some browsers may change the file extension. Verify that the filename and extension have not changed. The correct extension after the filename should be .upd. Do not rename the file or change the extension.

6. After the file is saved to the hard drive, copy the file to a 512 MB or higher capacity blank FAT or FAT 32 micro SD card root. The root of the drive is the topmost level, where the file is not placed into a folder.

Upgrading VesselView

Important considerations before and during the upgrade process:

- Have you backed up your waypoints, routes, and tracks?
- Each display must be upgraded individually; there is no automatic network feature to upgrade multiple VesselViews simultaneously.
- Do not turn off the display or disrupt the power during the upgrade process.
- Do not remove the micro SD card during the upgrade process.

1. Verify that the ignition key is off and that the VesselView is not turned on.

NOTE: Some installations may have the VesselView powered up with a dedicated circuit, rather than by the ignition key-on circuit.

IMPORTANT: VesselView must be turned off for at least 30 seconds before upgrading the software.

2. Insert the micro SD card into the card reader port all the way until it clicks and stays in place.
3. Turn the ignition key on and verify that the VesselView is on.
4. Allow the system to boot up. A screen will prompt you to upgrade or cancel.
5. Use the rotary knob to highlight the upgrade file and press the knob to confirm.

Select update to run

0: Cancel (Do not run updater)

*1: VesselView 7-X.0.XX.XXX-XXXXX

56565

6. Do not turn the ignition key off, turn VesselView off, or remove the micro SD card while the software is uploading. The upgrade process may take several minutes to complete.

Installing update. Please wait...
Do not turn off during update,
as this may damage your device.

56562

7. When the upload is finished, remove the micro SD card and the system will automatically reboot to complete the upgrade.


Update complete.
Please remove the SD card to finish.

56563

8. Verify that the software version upgraded is the correct version. Press the Go To button, press Settings, select Systems and rotate knob to About. Press the knob to verify. The current software version is shown. Keying the vessel off for 30 seconds, then keying on will also display the software version in the lower right-hand corner of the initial boot up screen.

Touch-Screen Calibration

1. Turn the unit off for at least 30 seconds.
2. Press and hold the MENU button, then turn the unit on.
3. Hold the MENU button down during power on, until the calibration utility screen comes up—approximately 15 seconds.



56947

Calibration utility screen

4. Touch crosshair shown on-screen to perform nine points of calibration.
5. After successful calibration, the unit will return to the normal application screen.

Creating Screen Captures

VesselView 7 has the ability to capture complete screens and store them for download to a SD card. When the unit is powered up and the capture of a screen is wanted, press the Power button and then the GoTo/Pages button together. A notification tab will appear on the bottom of the screen, containing the image number of the screen capture. This notification tab will not be present on the captured screen.




60146

VesselView has an internal memory capacity of approximately 80 Mb. It is recommended that files such as screen captures, waypoints, tracks, and routes be backed up on an SD card or other external storage device, and the internal memory kept as clear as possible. By default, all of the screen captures are stored in a Screenshots folder in My Files. The My Files folder can be accessed by pressing the GoTo/Pages button to access the Tools screen. From the Tools screen, touch the Files icon to open the folder.




60147

Open the Screenshots folder by selecting the drop-down arrow. To select all screenshots at once, select the Screenshots icon on the far right and select the Copy all... option. To select a single screen capture, use the rotary knob to scroll to the desired image. Press the rotary knob or touch the screen capture file.



60148


A window will appear with options to View, Copy, Rename, or Delete. Select Copy to download the image from the VesselView.



60149

Section 1 - Getting Started

With a SD card loaded into the VesselView, select Memory Card as the destination for the file and touch OK. Close the window by touching the X in the upper right corner. This will take you back to the My Files folder. To download additional images, follow this procedure.




Non-Mercury Marine Menus

Operators may find themselves out of the recognizable Mercury Marine screens of the VesselView. These menus and options are referred to as the Navico® side of VesselView. Mercury Marine does not support these components of the unit. For additional information on this side of the VesselView, please contact Navico®. To get back to the navigation screens of the Mercury Marine side of the unit, press the GoTo/Pages button, the Pages screen will appear. Select the Mercury Marine logo in the bottom center of the screen.



Another option for returning to the Mercury Marine VesselView navigation screen is to touch the application toggle button in the upper left corner of the screen.



Maintenance

IMPORTANT: It is recommended that the supplied sun cover be installed for protection when the unit is not in service.

Display Screen Cleaning

Routine cleaning of the display screen is recommended to prevent a buildup of salt and other environmental debris. Crystallized salt can scratch the display coating when using a dry or damp cloth. Ensure that the cloth has a sufficient amount of fresh water to dissolve and remove salt deposits. Do not apply aggressive pressure on the screen while cleaning.

When water marks cannot be removed with the cloth, mix a 50/50 solution of warm water and isopropyl alcohol to clean the screen. Do not use acetone, mineral spirits, turpentine type solvents, or ammonia based cleaning products. The use of strong solvents or detergents may damage the antiglare coating, the plastics, or the rubber keys.

It is recommended that the sun cover be installed when the unit is not in use to prevent UV damage to the plastic bezels and rubber keys.

Media Port Cleaning

The media port door area should be cleaned on a regular basis to prevent a buildup of crystallized salt and other debris.

Notes:

Section 2 - Initial Screens and Setup Wizard

Table of Contents

VesselView 7 Startup Warning Screen.....	14	Data Source Setup	22
Splash Screen.....	14	Display Screens.....	24
Setup Wizard.....	14	Startup.....	24
Import Configuration	15	Engine Off, Ignition On	24
Engine Setup	15	Engine Running at Idle	24
Display Setup	17	System Scan - Scan Report.....	25
Device Setup	18	Communication Errors	26
Units Setup	18	Engine Fault.....	26
Tank Configuration	18	Fault Navigation	26
Speed Setup	21	Engine Scheduled Maintenance.....	27
Finishing Setup Wizard	21		

VesselView 7 Startup Warning Screen

When VesselView 7 is started, a warning screen pops up and advises the operator not to rely on the product as a primary source of navigation and that the user assumes all liability for operation and associated risks.

Splash Screen

When the ignition key is turned on, a Mercury startup splash screen will appear. The number of engine hours will be displayed for up to four engines. In the lower right-hand corner of the screen is the software version. Power packages with emissions control will show an engine icon in the lower left-hand corner of the screen.




51617

Mercury splash screen

Setup Wizard


IMPORTANT: Do not rush VesselView by pressing buttons while the system is booting up to acquire vessel and engine data. When VesselView is initially started or after a factory reset, the system will take a few seconds to complete the boot up process.

The VesselView setup wizard guides you through the first steps of configuring the VesselView. The setup wizard can be accessed at any time through the SETTINGS icon in the scroller menu. Select the scroller bar arrow and swipe or use the rotary knob to select the Settings icon. To start the setup wizard, navigate to Settings>System>Setup Wizard. Select Next to continue.



56836


Settings icon in the scroller bar



59868

Import Configuration

To import an existing vessel configuration, insert a FAT or FAT 32 micro SD card with the configuration file and select this file in the drop-down menu. If there is no import file, select Next to continue.



59869


Engine Setup

1. In the Engine Setup screen, use the rotary knob or touch the menu fields to select the correct option.
2. Complete selections in the Engine Setup screen. When finished making selections, select Next to continue.



59870


Engine setup screen




Engine type selection



Engine model selection




Joystick selection



59874


Number of engines selection



59875

Display Setup

Depending on the number of engines indicated in the Engine Setup screen, select the engines to be displayed by this VesselView unit. Up to four engines can be selected. Select Next to continue.




59876

Engines to be displayed

Device Setup

In the Device Setup screen, use the rotary knob or touch the menu fields to select the proper options. If using multiple VesselView devices, be sure to assign unique numbers to each unit, to avoid data problems. Helm numbers should match the location of the individual VesselView unit. It is common to make the main helm 1 and the secondary helm 2. Select Next to continue.




- a - VesselView identification field
- b - Helm identification field

56747

Units Setup

Select the units of measure that VesselView will display on-screen data; speed, distance, and volumes. Particular units of measure can be changed later.




59879

Units of measure selection

Tank Configuration


In the tank setup screen, tank type, capacity, and tank name can be assigned for up to 8 tanks. The % column will display the live tank volume. Selecting the refresh button will query the tank sensors and refresh the readings.

The unmonitored tank is a tank that does not have a sensor associated with it.



59880


Use the rotary knob or touch the tank row to be customized.



59881

Select the tank type


Use the on-screen keypad to enter the capacity. When finished entering tank capacity data, select OK to close the keypad.



59883


Section 2 - Initial Screens and Setup Wizard

The tank position will populate the name field. To change the name of the tank, select the field and use the on-screen keypad to customize the tank name.




59884

After entering a tank name, touch Enter on the keyboard to continue to the next tank row in the Tank Setup screen. When all tank customization data has been entered, select the Refresh button in the lower corner. Check all data fields for accuracy, and select the Next button to continue with the Setup Wizard.




59886



59959


Speed Setup

In the Speed Setup menus, there are three options for determining how VesselView will acquire speed information. If the vessel is equipped with a GPS, the drop-down menu will allow selection of available devices. If the vessel is equipped with a pitot sensor, this option will be selected. If the vessel is equipped with a paddle wheel, then an option to select will drop-down. After the speed source has been selected, select Next to continue.



59887

The pitot and paddle wheel source selection is shown in the following illustration. Select the engine or drive unit that transmits the speed data to the VesselView.




60056

- a** - PCM0 = starboard outer
- b** - PCM1 = port outer
- c** - PCM2 = starboard inner or center
- d** - PCM3 = port inner

Finishing Setup Wizard

Select Finish to complete the Setup Wizard on the VesselView. Do not power off the unit until the Finish screen is replaced by the vessel activity screen.



56760

Data Source Setup

VesselView will ask to setup detectable data sources. Select OK to continue.




56761

Power on all products and key on all engines to ensure that all data generating sources can be detected. Select Start to begin the process.



56762



56763

NOTE: If Cancel is selected by accident, data source setup can still be completed by navigating to Settings>System>Network>Auto select. Auto select will scan the vessel network and identify all compatible devices onboard.

When Auto select is complete, select Close.




56764

VesselView will display the System screen. Systems operating within established parameters will display in green.



56765

Selecting the System OK field will display engine hours.



56766

Display Screens

Startup

On startup after the splash screen sequence, the main display will load and all data and graphics will be active. Two conditions are available: engine off or engine running. The following chart and information explain the sequence for how the constant and user-selected data areas change.

NOTE: The VesselView display may appear off, but the unit remains awake for 30 seconds after keyoff.

Engine state	User-selected data area
Engine off, ignition on	Good stewardship message
Engine cranking	System scan in progress, animated propeller is shown
Engine running at idle	Propeller color turns green
Engine running in gear	Level 1 user selected data

Engine Off, Ignition On


The Mercury good stewardship message screen is displayed in the user-selected data area when the ignition is on and the engines are not running. All functions will be available and there will be no engine data displayed.

- The Mercury good stewardship messages are randomly selected. Examples include: Do you have flotation devices, and Mercury reminds you to please boat safely.
 - The good stewardship list items are subject to change depending on engine type or personality configuration.

Engine Running at Idle

When the engine is running, the user-selected data area of the display will show a green propeller when the system scan report is finished.

- The user-selected data area of the screen will display an animated propeller and progress bar to indicate a scan is in progress.




56963

- a** - Animated propeller
- b** - Progress bar

- If at anytime the engine is shifted into gear, the system scan will stop and the propeller will turn green, and user-selected data will appear.

- When the scan is complete, various content related pop-ups can appear: engine faults, maintenance reminders, communication errors, or system OK scan report.



System Scan - Scan Report

When a system scan is completed and there are no faults, maintenance reminders, or communication errors, the user-selected data area will display SCAN COMPLETE with a report and a good stewardship message. The scan report will be displayed until the engine is put into gear or the X button is pressed.

- The good stewardship messages are randomly selected. Examples include: Do you have flotation devices, Mercury reminds you to please boat safely.
 - The good stewardship list items are subject to change depending on engine type or personality configuration.




Scan complete



Good stewardship message

Communication Errors


When a system scan encounters a communication error, the scan will stop and all data fields will be displayed with dashed lines. The system status field will be gray with an X in a red circle and text reading Comm Error.



Communication error

Engine Fault

If an engine fault is detected during a system scan, the user-selected data area will display descriptive text on a bold color fault screen. The color of the fault screen will depend on the type of fault detected. The system status field in the lower left-hand corner will change according to the fault that is displayed.




- a - Warning icon with fault title
- b - Short text or legacy text
- c - Engine fault location
- d - Action text
- e - Number of faults

Fault Navigation

When faults are present, they will take over the user-selected data area. Faults will be identified with numbers along the bottom of the user-selected data area.

1. The user-selected field will default to the first fault and will have a white-filled box with a black number.
2. The selected fault will alternate between the fault number and a positive (+) symbol indicating there is more data to display.




3. When a positive (+) symbol is available, additional data related to that fault can be viewed.
4. When the additional data requires more pages, the fault area will show one or more circles. The selected page circle will be white. This area will show the long text description of the fault.
5. To exit the fault field, use the X button.

Engine Scheduled Maintenance


If a maintenance reminder is detected during a system scan, the user-selected data area will display descriptive text. The system status field in the lower left corner will change according to the maintenance issue that is displayed. Use common sense to protect your investment, and check your engine oil on a regular basis, preferably before each use.

1. When the scheduled maintenance time is fully depleted, the user-selected data area will display a general maintenance reminder to perform the scheduled maintenance.




2. Open the + icon to expand the text. You can reset the maintenance to 100% or exit the screen.

NOTE: The wrench icon maintenance reminder will be displayed in the system status field until the reminder is cleared from the system.



3. After resetting the maintenance reminder, the wrench icon no longer appears in the system status field.



Notes:








Section 3 - Screen Overview and Operation

Table of Contents

System Status Field Functionality.....	30	ECO Navigation.....	41
Enlarging Data Boxes.....	31	ECO Refresh	42
Auto Cycle	31	Minimize	42
Scroller Bar Functionality.....	32	Exit ECO	43
Scroller Bar Activation and Navigation	32	Changing ECO Targets.....	43
User-Selected Data Area	33	Changing Target Values	44
Scroller Bar Icons.....	33	Smart Tow Mode.....	44
X-Pand	33	Smart Tow.....	44
Temperatures	34	Features	44
Pressure	34	Enabling Smart Tow	46
Voltages	34	Smart Tow Targets	46
Fuel	35	Save	47
Tanks	35	Disabling Smart Tow	47
Advanced	35	Cruise Control Mode.....	47
Performance	36	Cruise Control.....	47
Trim and Tabs	36	Cruise Control Data Area.....	48
Trip Log	36	Constant Data Area Change	48
Navigation	37	Cruise—User-Selected Data Area	49
Generator	37	Cruise Navigation	49
ECO	37	Autopilot Mode.....	50
Autopilot	38	Autopilot Screen Overview.....	50
Cruise	38	Autopilot Screens Navigation.....	50
Troll	38	Minimize Autopilot	51
Smart Tow	39	Troll Control Mode.....	51
Settings	39	Troll Control.....	51
Economy Mode.....	40	Troll Control Data Area.....	52
ECO Mode.....	40	Constant Data Field Change	52
ECO Minimum and Maximum Values	40	Troll—User-Selected Data Area	52
ECO RPM and Trim Targets.....	40	Troll Navigation	53
Target Colors	41		


System Status Field Functionality

The system status field is used to communicate specific engine information and active modes. It will always be visible on the main screen in the lower left corner of the display, unless a pop-up full screen warning is encountered. The color, icon, and text will change according to the system status, warnings, maintenance indication, and active modes. Your vessel personality and the type of power package installation will have a direct effect on which icons will be available in the system status field. Not all of the available icons are listed in the following table.

System Status Examples	
 <p>51875</p>	<p>Engine icon when ignition is turned on. The icon is only visible if the power package has emissions control.</p>
 <p>52099</p>	<p>Communication error when the ignition is turned on. The power package is not communicating through the control area network.</p>
 <p>52100</p>	<p>Indicates that every component connected to the control area network is within normal operating parameters.</p>
 <p>52101</p>	<p>Warning icon indicates that there is a fault.</p>
 <p>52102</p>	<p>Warning indicating the starboard engine onboard diagnostic has detected a fault. All other fault identified engine locations will appear similar.</p>
  <p>52104</p>	<p>Autopilot waypoint tracking. The orange color indicates waypoint tracking is active and computer controlled. If autopilot waypoint tracking is in standby mode (not active) the color of the field will be gray. This color scheme change is the same for all autopilot functions.</p>

Enlarging Data Boxes

Data boxes can be enlarged by highlighting the expand (X-PAND) icon and pressing the rotary knob.




Expand icon

After the icon is activated, the user-selected data area will be filled with the enlarged data from the actively displayed data selection. Up to six data selections can be enlarged, one at a time, and will cycle in the chronological sequence shown in the following illustration.



Each data field has its own page indicator in the lower left-hand corner of the user-selected data area. Touch the various page indicators to view additional selections. Touch the auto cycle icon to have all data selections cycle through a chronologically entered sequence.



- a - Page indicators
- b - Auto cycle icon
- c - Exit icon

Auto Cycle

- When auto cycle is selected but not active, the icon will be displayed on a white field.
- Press the rotary knob to activate the auto cycle. The icon will be displayed on a blue field with white arrows and will remain this color scheme until auto cycle is disabled. The default time for auto cycle is five seconds per page and can be changed in the Settings menu.
- To turn off auto cycle, highlight the X and press enter or touch the auto cycle icon. The auto cycle will exit the user-selected data area.

Scroller Bar Functionality

The scroller bar provides access to icon items not currently displayed in the user-selected data area of the screen. Scroller bar icons will be hidden until the scroller bar is activated. Touching the on-screen scroller bar arrow MENU tab will extend the scroller bar. Swiping right or left will take you through all scroller bar options. If no selection is made, the scroller bar will auto-hide in five to thirty seconds, depending on the scroller bar settings option. When an icon is selected, the user-selected data area will be transformed to show icon name and data pertaining to that feature.

Scroller Bar Activation and Navigation

1. Touch the scroller bar arrow MENU tab in the bottom right-hand corner of the screen.



2. Use the rotary knob to highlight the icon you would like displayed and press the rotary knob to activate it. A white background box will highlight the scroller bar icon to be selected. Navigating by swiping in the scroller bar, and touching an icon will give you the same results as the rotary knob.

NOTE: An arrow icon will appear to the left and right of the scroller bar. When only one arrow icon is visible, you must move in the direction indicated by the arrow. When both arrows are visible, either direction can be toggled or swiped.



- a - Selected icon
- b - Scroller bar arrows


User-Selected Data Area

During the scroller bar navigation process, when the icon is highlighted using the rotary knob, the user-selected data area will change to display the icon, the icon name, and a description of what the feature does. The user-selected data area will show this information for up to 30 seconds, unless the rotary knob is pressed. Similarly, when using the touch and swipe method of scroller bar navigation, touching the icons while swiping will display their name and feature description. A nonswiping, stationary touch, made within the duration selected in the Preferences menu, will activate that data in the user-selected data area.



60256

Scrolling using rotary knob or swiping




60255

On-screen duration options

Scroller Bar Icons

X-Pand


X-pand—displays enlarged data from selected data screens. Selected data will cycle on-screen.



60267


Temperatures

Temperatures—displays engine and fluid temperature values for oil, water, and fuel. Displays environmental air and manifold air temperature. Available information is power-package dependent.




Pressure

Pressure—displays engine pressure values for water, oil, fuel, and boost. Available information is power-package dependent.




Voltages

Voltages—displays battery values for all engines.



Fuel

Fuel—displays fuel system statistics: current economy, average economy, volume use per hour, total capacity, and fuel used.




Tanks

Tanks—displays the vessel's onboard tanks data for fuel, water, waste, and two-cycle oil capacity.




Advanced

Advanced—displays additional engine information: manifold temperature, throttle percent, engine load, and manifold boost pressure. Available information is power package dependent.



Performance

Performance—displays advanced performance data: peak performance—RPM or speed and inches per revolution of the propeller.



Trim and Tabs

Trim and Tabs—displays drive trim position and position of tabs. A sensor must be installed on the tabs for this function to display information.



Trip Log

Trip Log—displays recorded trip data: total distance, total time, average speed, average fuel consumption. Trip log recorded data can be erased and set to zero.




Navigation

Navigation—displays data relating to the installed navigation system: compass heading, longitude and latitude, time to waypoint—TTW, bearing to waypoint—BTW, distance to waypoint—DTW, and course over ground—COG.



Generator

Generator—displays data the generator can send through a NMEA 2000 or J1939 protocol control area network: current run/ stop state, voltage—AC/DC, hertz, hours, oil pressure, and water temperature.



ECO


ECO—displays information to guide the operator to the best trim position and engine speed to achieve the best fuel economy.
NOTE: Refer to **Economy Mode** in this section for additional operating information.



Autopilot

Autopilot—displays autopilot data.

NOTE: Refer to **Autopilot Mode** in this section for additional operating information.



Cruise

Cruise—activates cruise control. Allows the user to control the vessel with the engine RPM or vessel speed. Vessel speed control requires a paddle wheel sensor or GPS.

NOTE: Refer to **Cruise Control Mode** in this section for additional operating information.



Troll

Troll—activates low-speed engine control. Can be used to control engine RPM.

NOTE: Refer to **Troll Control Mode** in this section for additional operating information.



Smart Tow

Smart Tow—activates Smart Tow profiles for selection. Profiles can be modified, added, and saved.

NOTE: Refer to **Smart Tow Mode** in this section for additional operating information.



Settings

Settings—the main location where data can be turned on or off, modify sensor data tolerance \pm , select preferred displayed values—metric/English/nautical, and reset to factory default.

NOTE: A reset to factory default will erase all customized settings. See Section 4 for details.



Economy Mode

ECO Mode



57376

ECO mode displays information to guide the operator to set the optimum trim position and engine speed to achieve the best fuel economy. The engine control module (ECM) or propulsion control module (PCM) calculates the best fuel economy based on information from various sensors on the power package and vessel.


1. Touch the on-screen scroller bar tab to open the scroller bar.
2. Use the rotary knob, or swipe to find the ECO Mode icon and touch the icon or press the knob. The user-selected data area will display the ECO icon element with a short description on how to achieve the best fuel economy.



60496

ECO Minimum and Maximum Values

When ECO mode is active, the minimum and maximum value target lines will appear in the RPM sweep. These lines display the active optimized range that is to be calculated. The target lines can be adjusted in the Settings menu.





60572


ECO RPM and Trim Targets

When the RPM values reach the minimum value range, RPM and trim targets will appear. A colored line will span the RPM sweep with colored targets to inform the user where the target values are and will change color when they have achieved optimization.

Target Colors


Triangle Color Rules				
State	Color	Fill value	Action	Image
Target not achieved	Yellow	Outline	Blinking	 52170
Target achieved	Green	Solid	Continuous	 52171

The following shows an example of ECO RPM and trim out of optimization.



RPM and trim settings are not optimized

When all targets have been achieved, the user-selected data area screen will change from instructions to displaying OPTIMIZED with the current fuel economy value.



ECO Navigation

The user-selected data area footer will display REFRESH, MINIMIZE, and X.

- Minimize will hide ECO instructions and display ECO MODE in the system status screen footer. Minimize allows the user to display other information in the user-selected data area.
- Refresh will reset the ECO values and use new parameters for determining the RPM and trim target values.

Section 3 - Screen Overview and Operation



- X will close the ECO mode program, removing the RPM and trim targets from the user-selected data area.



ECO Refresh

Refresh allows you to recalculate the current values that ECO uses for the RPM and trim targets.

1. Highlight the refresh feature and press enter.
2. Instructions appear in the user-selected data area. Highlight the refresh feature again to confirm and press enter.




3. When the system has finished calculating new targets, the user-selected data area will change to indicate that the values have been refreshed.
4. The ECO user-selected data area will show the new target values on how to achieve optimization for the best economy.

Minimize

Minimize is a feature that allows the user to continue with the ECO features while displaying additional information in the user-selected data area.

1. When minimize is selected, the ECO instructions will be removed and then display additional information in the user-selected data area. You can also select items from the scroller bar.

NOTE: The items available on the scroller bar are dependent upon information available from the gauge and vessel personality.



60577


2. When minimize is active, the system screen footer will display the ECO icon.
3. To enlarge ECO mode, touch the icon in the screen footer.

Exit ECO

To exit the ECO mode, select the X in the user-selected data area footer and VesselView will turn off the ECO function.

Changing ECO Targets

The software for ECO monitors the engine sensors and looks for the best fuel economy number while the vessel is in operation. When the software recognizes an improvement in the fuel economy, VesselView records the trim and engine RPM values at that time. This calculation happens whether the ECO screen is visible or not. When the software has recorded the RPM and trim values, it will guide the operator with arrows to that optimum running speed and trim setting. In most applications the ECO screen does not need any calibration, although there are settings to customize the gauge for your boating style. The default settings are within acceptable parameters for most vessel applications. The following are the default settings.



60588

Default ECO Target Settings

Fuel economy stability	0.7 seconds
RPM stability	0.8 seconds
RPM window minimum	2000 RPM
RPM window maximum	4000 RPM
RPM target proximity	10%
Trim target proximity	3%

IMPORTANT: A manual trim calibration must be performed before the ECO screen can be used if a vessel personality was not uploaded with a micro SD card. Using a default trim calibration will not allow the ECO screen to function properly.

Changing Target Values

1. Open the scroller bar.
2. Select Settings, and press the enter button.
3. Go to Engines and press enter.
4. Highlight ECO Mode and press enter.
5. Highlight the target value you want to change.
6. Change the target data and press the enter button.
7. Continue this process until you exit the target.

NOTE: The settings menu will close after exiting the target. To change other target values, open the scroller bar. The Settings icon will be highlighted. Follow the same process as previously outlined to change other target values.

Smart Tow Mode


Smart Tow



57377

Smart Tow is an easy to use program to manage boat acceleration and target speed goals for pulling skiers, tubers, or watersport equipment of all varieties. Smart Tow takes the guesswork out of acceleration problems like too much hole shot, too much overshoot, deceleration, and constant speed targets. Select a profile, select enable, and place the control handle to wide-open throttle, Smart Tow will do the rest.

The Smart Tow screen allows you to select, set, and modify settings in the Smart Tow features. The launch graph dot is animated when Smart Tow is active and performing a launch sequence. The dot will move along the launch path showing what part of the launch sequence the system is performing.



52188


Launch graph animated dot

Smart Tow is based on the engine RPM unless the vessel has a GPS installed and connected to the control area network. When the vessel contains a GPS, you can select either speed targets or engine RPM targets for Smart Tow control options. You can also create custom launch profiles.

Features

Smart Tow utilizes the user-selected data area and the footer section to allow you to adjust the settings. Touch or swipe to move through the selection box fields. The footer section allows you to enable or disable Smart Tow, save, or exit. The items located in the data area footer require the selection to be touched or use the rotary knob to highlight and select.

Smart Tow offers five factory preset launch profiles, or the operator can create new custom launch profiles. Custom profiles are helpful when there are people onboard with varying levels of experience with watersports equipment. The operator can create more aggressive launches for experienced skiers, as well as milder launches for children or inflatables towing.




60305

Factory presets

There are five selection fields within a profile. Use the rotary knob or touch to change the profile selections.


- Set point is the RPM or speed. The operator can adjust the RPM or speed by touching the data screen area.
- Ramp is the time that the boat will take to get to the set point.
- Overshoot is the percentage over the set point the boat will achieve.
- Overshoot duration is the length of time that the boat will remain above the set point.

After making adjustments to the desired settings, select NEXT in the data area footer. This will take the operator to the keyboard screen, to name and save to the profiles list. Name the profile and select the Enter key to add the new profile to the list.



- a - Set point—desired speed of boat
- b - Ramp—time to set point
- c - Overshoot—percentage above set point
- d - Overshoot duration—time the boat will exceed set point
- e - Next—takes the operator to the save options

60312




- a - Name entry
- b - Enter key

60313

Section 3 - Screen Overview and Operation

- Enable or disable turns the feature on or off. The RPM sweeps will be displayed as nonactive white sweeps when disabled. The RPM sweeps will be displayed as active orange sweeps when enabled. The operator can modify all settings when Smart Tow is in the off—disabled state.



60314

- Enable—on, is green when ready
 - Disable—off, is red when not active
- Press SAVE. Save will modify the Smart Tow screen to allow the operator to choose quick save, save as new, create custom, or delete the profile.
 - If the operator presses on the X, Smart Tow is disabled and the constant and user-selected data area returns to the default screen.


Enabling Smart Tow

To activate Smart Tow, select a preset launch profile or a custom-made profile. When the vessel and person being towed are ready, place the throttle lever in the full throttle position. Smart Tow will begin the launch profile. A moving dot will move along the profile path, indicating the current progress of the launch profile.

The boat will continue at the set RPM or speed target until disable is selected, or until the operator moves the throttle lever to the idle position.



Smart Tow Targets

Smart Tow will modify the constant data area by incorporating RPM and overshoot indicators within the RPM sweeps. The RPM set point target will be the color orange and the overshoot scale will be the color white.



52180

The RPM set point target will change from an outline when not active, to a solid when activated.

RPM Set Point Target			
State	Color	File value	Image
Set-up point	Orange	Outline	 52182
Active	Orange	Solid	 52183

When Smart Tow is not active, the RPM sweep display is white. Smart Tow will modify the color of the RPM sweep display to orange when active.




56976

Active RPM sweep display color is orange

Save

When the operator selects save, the user-selected data area will transition to the save options.

- Press on the selection to confirm.



60310

- a - Quick save
- b - Save as new
- c - Create custom
- d - Delete

- **QUICK SAVE** will store the existing profile with the new RPM or speed values. Select to save the data and return to the Smart Tow screen.
- **SAVE AS NEW** allows the operator to store the current setting with a custom name. Select to transition to the custom file name.
- **CREATE CUSTOM** allows the operator to create another custom launch profile.
- **DELETE** will erase the selected launch profile.

Disabling Smart Tow

To exit out of Smart Tow, DISABLE must be selected. VesselView will transfer throttle control back to the operator. When Smart Tow is enabled, moving the throttle lever to any point below the speed target will decrease the speed of the boat, but the top speed of the boat will not increase beyond the target speed.

Cruise Control Mode


Cruise Control



57378

Section 3 - Screen Overview and Operation

The cruise feature allows the operator to select a set point and adjust the value so the vessel maintains a specific speed or engine RPM.



60597

Speed based and RPM based displays

- Cruise is RPM based, unless the vessel incorporates a Mercury Marine GPS into the control area network.
- If the vessel has a Mercury Marine GPS, the default setting is vessel speed.
- The operator can select either RPM set points or speed-based set points. The type of cruise option can be changed in the Settings menu.
- Open the scroller bar and highlight the Cruise icon.

To enable Cruise Control, select the set point, touch ENABLE, and put the throttle handles in the wide-open throttle position. These instructions will be displayed on the screen.



60598

Speed based and RPM based displays

NOTE: Cruise Control can be disabled by placing the remote control levers in neutral.


Cruise Control Data Area

Constant Data Area Change

Cruise will modify the constant data area of the screen by incorporating an RPM indicator within the RPM sweep, similar to Smart Tow and ECO mode targets.

- When cruise mode is activated, data will be modified to communicate:
 - RPM set point.

- RPM sweep color will change to orange when active to indicate the engine is computer controlled.




- a - Cruise not active
- b - Cruise active

60600

Cruise—User-Selected Data Area

Cruise will modify the user-selected data area of the screen when active.

- Elements within the user-selected data area will change to allow the user to set-up:
 - RPM set point.
 - Cruise status enable or disable.



- a - Set point value
- b - Instruction
- c - Enable
- d - Minimize
- e - Exit

52279

Cruise Navigation

Cruise mode will have a modified navigation system similar to Smart Tow. The user-selected data area footer allows the operator to enable or disable cruise, minimize, or exit. Footer navigation will follow the same basic navigation selection strategy as other features.

- Use the rotary knob or swipe to scroll through the selections in the footer.
- Press the knob to activate the selection.
 - Enable or disable turns the element feature on or off.
 - Minimize will hide cruise data and display CRUISE in the system screen footer. This allows the operator to display information from other selected icons.
- The set point adjustment selection field will be the default location at cruise start-up. After making adjustments to the desired settings, use the rotary knob to move the cursor to the enable/disable selection in the user-selected data area footer.
 - Use the rotary knob to move between the set point selection and the footer.
 - When the selection tab is outside the footer navigation area—set point field, the operator only needs to use the rotary knob to make RPM or speed adjustments. There is no need to press the knob to engage the new setting.
- Minimize is a feature that allows the operator to use the cruise feature while displaying additional data in the user-selected data area.

IMPORTANT: Set points cannot be adjusted when cruise is minimized.

- Scroller bar icon selection is limited. Items that are not accessible will be grayed out when cruise is active.
 - If autopilot is active, and cruise is minimized, the system status screen footer will display CRUISE.
 - Cruise data will be displayed over autopilot settings if the user selects the system status field.
 - If an autopilot pop-up notification occurs or the operator uses the autopilot CAN trackpad, autopilot data will automatically fill the user-selected data area. The operator will have to minimize to hide the pop-up data.
- After minimize is activated, the system screen footer will display CRUISE.
 - When exit is selected while displaying cruise, the cruise feature will be disabled. The cruise icon will be displayed next to the system status field until another icon is selected from the scroller bar.

Autopilot Mode

Autopilot Screen Overview



57380

VesselView is a display extension for autopilot and joystick operations. All functionality of these features are controlled through the Mercury Marine autopilot control area network (CAN) pad. VesselView will show if the mode is active or in standby; pop-ups will appear as the vessel arrives at a waypoint, asking to acknowledge the turn, and display text on how to adjust the engine and drives to achieve maximum efficiency.



60594

Autopilot Screens Navigation

Autopilot screens will have a modified navigation system. Information will be displayed on two pages of data. Page indicators and an X will be the only selections available.

- Page 1 will contain base autopilot information.
- Page 2 will contain additional navigation data.



60595

- Use the X to hide autopilot data and display the autopilot mode in the system data field. This allows other information to be displayed in the user-selected data area.



52461

- a - Page indicators
- b - Hide autopilot data

Minimize Autopilot

When X is selected in the user-selected data area footer, autopilot data will be removed. You can select items from the scroller bar for display in the user-selected data area. The last user-selected data will be displayed by default.

NOTE: Available scroller bar items are based on the engine selected in the Setup Wizard.

- When ECO is active and autopilot is minimized, the system status field will display AUTO.
- Items in the scroll bar that cannot be selected will be gray when autopilot is active.
- When an autopilot pop-up occurs, or a button on the autopilot CAN pad, autopilot data will automatically fill the user-selected data area. You must select X to hide the data.
- The system status field will display what mode autopilot is in: track, auto, waypoint sequence, or standby. Waypoint sequence will display orange in the system status field, all other modes will display gray.

Troll Control Mode

Troll Control



57379

The troll feature allows the operator to select a set point and adjust the value so that the vessel maintains a specific speed or engine RPM.



60591

- Troll is RPM based, unless the vessel incorporated a Mercury Marine GPS into the control area network.
- If the vessel has a Mercury Marine GPS, vessel speed is the default setting.
- The operator can select either RPM set points or speed based set points. The type of troll option selection can be changed in the Settings menu.

NOTE: The power package will know that it is in Troll mode, and will limit the RPMs to 1000 regardless of an amount entered higher than 1000 by the operator.

Troll Control Data Area

Constant Data Field Change


To activate troll control, the power package must be in gear and the engines set to idle.



60592

Troll will modify the constant data field of the screen by incorporating an RPM indicator within the RPM sweep, similar to Smart Tow and ECO mode targets.

- When troll control mode is activated, elements of the constant data field will be modified to communicate:
 - RPM or speed set point.
 - RPM or speed sweep color will change to orange when active to indicate the engine is computer controlled.



60593


- a** - Not enabled
- b** - Enabled

Troll—User-Selected Data Area

Troll will modify the user-selected data area of the screen when active.

- Elements within the user-selected data area will change to allow the user to set-up:
 - a. RPM set point.

- b. Troll status enable or disable.



- a - Set point value
- b - Enable or disable
- c - Minimize
- d - Exit

Troll Navigation

Troll mode will have a modified navigation system similar to Smart Tow. The user-selected data area footer allows the operator to enable or disable troll, minimize, or exit the program element. Footer navigation will follow the same basic navigation selection strategy as other features.

1. Use the rotary knob or touch to go through the selections in the footer.
2. Select to activate the selection.
 - a. Enable or disable the element feature.
 - b. Minimize will hide the troll data and display Troll in the system status field. This allows the operator to display information from other selected icons.
3. The set point adjustment selection field will be the default location at troll start-up. After the operator makes adjustments to the desired settings, enable in the data area footer.
 - a. Use the rotary knob to move between the set point selection and the footer.
 - b. When troll is enabled, highlighting the set point field allows the operator to increase or decrease the set point without disengaging Troll. Adjustments can be made anytime that Troll is enabled.
4. Minimize is a feature that allows the operator to use the troll feature while displaying additional data in the user-selected data area.

IMPORTANT: Set points cannot be adjusted when troll is minimized.
5. After minimize is activated, the system status field will display Troll.
6. When X is selected while displaying the Troll element, the troll feature will be disabled. The Troll icon will be displayed next to the system status field until another icon is selected from the scroller bar.

Notes:

Section 4 - Setup and Calibrations

Table of Contents

Settings Menu Navigation.....	56	Engine Model Settings.....	72
Navigation to the Settings Menu.....	56	Limits Settings.....	73
System Settings.....	56	Supported Data Settings.....	74
Navigation.....	56	ECO Mode Settings.....	75
Language Settings.....	57	Cruise/SmartTow Settings.....	75
About Setting.....	57	Trim Settings.....	75
Helm and Device Settings.....	58	Trim Calibration	76
Setup Wizard Setting.....	59	EasyLink Settings.....	77
Restore Defaults Setting.....	59	Navigation.....	77
Network Settings.....	60	Preferences Settings.....	79
Simulate Setting.....	61	Navigation.....	79
Time Settings.....	61	Buzzer Settings.....	80
Vessel Settings.....	62	Backlight Settings.....	80
Navigation.....	62	Scroller Bar Settings.....	81
Tabs Settings.....	62	Data Boxes Settings.....	82
Tank Settings.....	63	Popups Settings.....	83
Tank Calibration	64	Auto-Cycle Interval Settings.....	85
Reverse calibration	64	Alarm Settings.....	85
Speed Settings.....	64	Navigation.....	85
Steering Settings.....	67	Alarms Settings.....	85
Camera Settings.....	69	Personality File Settings.....	86
Sea Temp Setting.....	69	Navigation.....	86
Depth Offset Setting.....	70	Settings.....	87
Engines Settings.....	71	Export Settings.....	87
Navigation.....	71	Import Settings.....	88
Engines Shown Settings.....	71	Restore Settings.....	89


Settings Menu Navigation

Navigation to the Settings Menu

- Changes in any of the settings can be made at any time using the Settings menu. All drop-down and flyout menus can be navigated by touching the screen or by using the rotary knob. The Settings menu can be accessed using the scroller bar at the bottom right of the screen.



- Swipe the menu bar, or turn the rotary knob so that the last icon is highlighted. The last icon is the Settings menu.
- Touch the Settings icon or press the rotary knob to enter the Settings screen.



System Settings

Navigation

Navigation through menus can be done by touching, or by using the rotary knob to select the desired tab. The active tab will be highlighted in red. A small arrow in the tab indicates that there are additional menus associated with the setting.

Language Settings

With the System tab highlighted, touch the Language tab or press the rotary knob.



59861

Swipe the slider at the right of the menu, or select the language with the rotary knob. When the desired language is highlighted, touch the selection or press the rotary knob.




59862

Any time that a new language is selected, the operator will be prompted to confirm the language change and the unit will restart, displaying the Restarting screen. When the VesselView powers up, all content will be displayed in the selected language.

About Setting

The About setting displays hardware and software information for the VesselView 7.



59863

Section 4 - Setup and Calibrations


The current software version can be viewed in this screen.



59864


Helm and Device Settings

The Helm and Device tab allows the user to assign the identification number and position of the VesselView. This setting is important when multiple VesselViews are installed. Assigning unique numbers to each VesselView and each helm location, on boats with more than one helm, is required for proper network function.



59865


Touch the screen or press the rotary knob to activate the Setup Helm and Device Numbers screen. Make selections, 1 through 4, in the Helm Number and Device Number menus. Changes made to this setting will require the unit to restart.



59866

Setup Wizard Setting


Setup wizard guides you through the first steps of configuring the VesselView. The setup wizard can be accessed at any time through the Settings menu. Setup wizard combines numerous individual setting options in one, easy to follow operation. Any settings set using the Setup wizard, can be changed at any time using the individual setting menu for that item. Please refer to **Setup wizard** in this manual for complete instructions.



59867


Restore Defaults Setting

Restore defaults. This setting restores the factory defaults. Any settings entered using the Setup wizard, or settings adjusted by the user are cleared.



60161


Options include; All settings, Engine limits, and Alarm history. Selecting the All settings option will require the unit to restart.



59892

Network Settings


Network settings allows the user to select numerous data sources, scan the CAN bus and NMEA backbone for installed data reporting (input and output) components, and review diagnostic reports—diagnostics shows data on errors and overruns on the CAN and NMEA communication networks. This can be useful for a skilled technician diagnosing CAN and NMEA communication errors. Device List shows all CAN bus and NMEA backbone data reporting components that are recognized.



59893


Auto Select will scan the network and identify any compatible devices.

Sources allows the operator to select the device which will transmit data to the VesselView. The default selection for each item is the VesselView.




59894

Device List will display all of the components discovered during the Auto Select process.



59895

Magnetic variation can be set to Auto, or the variation can be changed + or - up to 5 digits, including two decimal points.




Smart Contextual Enabled turns the display of the digital engine RPMs on or off in the user-selected data area.

CAN-H can be turned off for the purpose of diagnosing communication issues. During normal operation, this feature is always selected on.


Simulate Setting

Simulate mode takes VesselView off the network, and generates random data on the screen. Any data shown should not be regarded as accurate, or be used in the navigation of the boat. Simulate can be used to help the operator become familiar with VesselView before using it out on the water.



Time Settings

Time settings can be changed through the selection of; Local time, 12/24 hour format, and Date format.



NOTE: For the correct time to display, there must be a GPS source available.


Vessel Settings

Navigation

Navigation through menus can be done by touching, or by using the rotary knob to select the desired tab. The active tab will be highlighted in red. A small arrow in the tab indicates that there are additional menus associated with the setting.

Tabs Settings

Tab data source can be selected with this setting. Tab data sources include; tabs, TVMs, and PCMs.





59901

The following are the positions of the Tab source options.

1. PCM0 = starboard outer engine
2. PCM1 = port outer engine
3. PCM2 = center or starboard inner engine
4. PCM3 = port inner engine
5. TVM = pod drive
6. TAB = tab module


The Show option will determine if the tab data is displayed on-screen, checked = yes, unchecked = no.



60164

Tab calibration allows the operator to put the tabs in their uppermost and lowermost positions and record the percentages. This is useful for determining the true 0° trim position—the point at which the tabs are parallel with the bottom of the vessel. Correctly calibrated tabs will show an accurate position of the sliders on the screen.

To calibrate the tabs, trim the tab parallel to the hull, record the reading, this will be the tabs actual 0%. Trim the tab all the way down, record the reading, this will be the tabs actual 100%. Touch save to keep the new calibrated tab data.




- a - 0% trim
- b - 50% trim
- c - 100% trim


60169

Tank Settings

Tank settings and calibrations allow the selection of the type of tank, the capacity of the tank, and the calibration method for tanks.



59902



59886

Configure Tanks is covered during the Setup Wizard process, but changes can be made at any time.

Tank Calibration

There are many situations in which a tank may need calibration; odd shaped tanks, V-bottomed tanks, stepped-sided tanks, and even a tank's aspect when the boat is in the water. Floats and senders can send inaccurate data to the operator, causing problems with fuel and other volume display. The most accurate way to achieve tank calibration is to start with an empty tank with a known capacity. Pump one quarter of the capacity and record the float or sender position. Repeat this procedure in one quarter increments, recording the float or sensor position each time, until the tank is full.

Tank calibration allows the operator to adjust the full through empty readings of a tank. When a tank is highlighted, touch the arrow on the right side of the tab or press the rotary knob to activate the calibration screen.

The default readings are in the second column, and can be selected by touching or toggling with the rotary knob. In the following example, we know that the fuel tank is full, but we are receiving a reading of 79 percent full. Touch the record button in the 100 percent row, VesselView will now consider a reading of 79 percent as full, and adjust the half and empty readings accordingly. When the level of a tank is known to the operator, tank calibration can be used to correct the gauge reading to match the known level at any time.




When tank calibration is complete, touch Save and the unit will return to the navigation screen.

Reverse calibration


Reverse calibration uses the fuel consumption data to determine the level of the tank, and learns the position of the float or sender.

Speed Settings


Speed source settings are covered during the Setup Wizard process, but selection of GPS, pitot, and paddle wheel sources can be changed with this menu. Strategy and GPS are the options. If the vessel is equipped with a GPS—connected to the CAN network, choose this option. If the vessel is equipped with a pitot sensor and/or a paddle wheel, this option should be selected. A speed strategy using pitot sensors and paddle wheels is covered later in this section.



Speed source has the option of choosing a GPS and the GPS source, the CAN P or the CAN H network. A strategy using a pitot sensor and/or a paddle wheel can also be selected. Selecting the pitot or paddle wheel options brings up a selection of sources.




59888



60057

The PCM assignment to engine position is illustrated in the following graphic.





60056


- a** - PCM0 = starboard outer
- b** - PCM1 = port outer
- c** - PCM2 = starboard inner or center
- d** - PCM3 = port inner

Section 4 - Setup and Calibrations

The speed-through-water (STW) Threshold is the approximate transition speed where the calculations from a paddle wheel switch over to another source—GPS or pitot. The default speed can be changed by selecting the field and using the on-screen keypad to enter a new value.



Pitot type options include 100 psi and 200 psi. The 200 psi option only applies to select Mercury Racing outboard models.




The pitot multiplier will use 1.00 as a default setting and can be increased or decreased to correct speed display readings that read too high or too low. For a low speed reading, increase the pitot multiplier by touching the multiplier window and use the on-screen keypad to enter an amount. For a high speed reading, decrease the pitot multiplier by touching the multiplier window and use the on-screen keypad to enter an amount.

Paddle wheel frequency can be changed to match the requirements of different sensors. The frequency of the paddle wheel speed sensor offered by Mercury Marine is 4.9 Hz per mile or 5.7 Hz per knot. Check the instructions that came with the paddle wheel for specific information on the paddle wheel frequency output. Touch the multiplier window and use the on-screen keypad to enter an amount.

Selecting Auto correct will synchronize the paddle wheel to the output of the GPS. The slider bar can also be used to achieve that same result.


Calibration of the paddle wheel is accomplished by using a GPS enabled device to help the operator adjust the reading of the paddle wheel. Using the slider allows the operator to increase or decrease the paddle wheel sender data.



60061


Steering Settings

Steering source data can be selected to come from either the PCM or the TVM, with options to display the data on-screen, to invert steering input, and to establish a steering offset degree.



59905

The PCM assignment to engine position is illustrated in the following graphic.




60056


- a** - PCM0 = starboard outer
- b** - PCM1 = port outer
- c** - PCM2 = starboard inner or center
- d** - PCM3 = port inner

Selecting Show with the check mark will display the steering angle in degrees at the top of the screen. Unchecking the Show option will hide the steering angle display on the screen.

Section 4 - Setup and Calibrations




60177



60178

Show unchecked will hide steering display



60175



60176

Show checked will display steering

The Invert steering option is helpful when there is a VesselView which is rear-facing. In this case the steering data will match the operator's point of view.

Steering Offset is used to align the outboard, sterndrive, or inboard to zero degrees. When the drive is positioned perpendicular to the hull, the steering angle displayed on-screen may not match the steering sensor on the drive. To adjust for this variance, touch the Offset tab. The Steering Angle Calibration box appears. Touching the Calibrated row Zero button will apply the offset. Note that the offset does not change on the display screen until the Save button is selected.



60062

Offset being calculated during calibration




Offset applied after save

Camera Settings

Camera settings allow the user to view videos or camera sources on the VesselView screen. VesselView supports two video channels. You can select to view one channel only, or to cycle the screen between available video cameras. The cycle period can be set from 5 to 120 seconds. The display can be optimized by adjusting the video settings. The adjustments are individual to each source.

IMPORTANT: If the vessel does not have cameras installed, make sure that this option is unchecked. In certain situations, the VesselView can experience disruptions in data display if the Cameras installed box is checked and the VesselView cannot locate camera sources.



59906


Sea Temp Setting

Sea Temp source selection options are available to select from where the VesselView is receiving sea temp data.

Depending on the type of water temperature sender the vessel has, the operator can select the source of the data. PCM options are for vessels equipped with a SmartCraft sensor. The Airmar® options are for vessels equipped with the sensor hooked up to the 4-pin diagnostic connection on the engine. The chart shows the position of the engine that is being used to transmit temperature data to the VesselView.


SmartCraft sensor		Airmar sensor	
PCM0	Starboard outside engine	Airmar0	Starboard outside engine
PCM1	Port outside engine	Airmar1	Port outside engine
PCM2	Starboard inner engine or center	Airmar2	Starboard inner engine

SmartCraft sensor		Airmar sensor	
PCM3	Port inner engine	Airmar3	Port inner engine



59907

The offset allows the adjustment of the data coming from the water temperature sensor. Chartplotters and other devices that have a temperature transducer, may be displaying a slightly different temperature. To match the displays, an offset can be entered to adjust the VesselView data to other display devices onboard.




60205

Depth Offset Setting


Depth Offset is the distance from the transducer to the actual waterline. The offset default setting is 0.0 ft. To set an offset below the transducer, subtract from the depth offset. To set an offset above the transducer, add to the depth offset.



60160




- a** - Depth transducer
- b** - To set an offset below the transducer, subtract from the depth offset
- c** - No offset. Distance from depth transducer to bottom.
- d** - To set an offset above the transducer, add to the depth offset



59947

Touch the Offset window or press the rotary knob to bring up the input screen, enter the offset value.



59948


Engines Settings

Navigation

Navigation through menus can be done by touching, or by using the rotary knob to select the desired tab. The active tab will be highlighted in red. A small arrow in the tab indicates that there are additional menus associated with the setting.

Engines Shown Settings

Engines shown is covered during the Setup Wizard process, but display options can be changed in the Engines settings menu at any time. VesselView can display up to four engines, depending on the number of engines chosen during the Setup Wizard process. The operator can select which engines are displayed. Checking or unchecking the engine selection will determine which engines are displayed on the VesselView.




60200

Starboard engine checked



60201

Starboard engine data displayed



60202

Port and starboard engines checked




60203

Port and starboard engine data displayed

Engine Model Settings


Engine model settings allows the user to change power package descriptions. Engine models is covered during the Setup Wizard, but changes can be made anytime. Any changes made here may make other settings and display options unavailable in VesselView. Use the rotary knob to help scroll through the list of engines, press the rotary knob to make a selection.



59909


Limits Settings

Limits helps set specific ranges for many engine data parameters, such as; RPM, coolant temperature, oil temperature, battery voltage, and boost pressure. Changes made to limits will not affect the engine package or the operation of Mercury's Engine Guardian programming. The actual engine limits are determined by the factory programmed control module on the engine.




59910

Examples of engine parameter limit screens are shown. From left to right are; RPM limits, Oil Temperature limits, Battery Voltage limits, and Coolant Temperature limits.



59951


Setting	Description
Min:	The value of the base of the on-screen graph
Max:	The value of the top of the on-screen graph
Warning low:	The value at the top of the lower red color section of the on-screen graph
Warning high:	The value at the bottom of the upper red color section of the on-screen graph



60208


- a - Min:
- b - Max:
- c - Warning low:
- d - Warning high:

The following example shows how the red colored warning ranges are changed on the graphs, due to changes of the maximum and minimum data values.




60212

Input values




60210

Graph result



60213

Input values




60211

Graph result

The default minimums and maximums are factory preset to the engine package chosen during the Setup Wizard or the Engines Setting menu. Enlarging or shrinking the warning minimums and maximums is generally regarded as the boater's personal preference.

Supported Data Settings


Supported Data settings allows the operator to select which engine and drive information is displayed on the screen. Data boxes are preselected based on the engine model selected, but can be changed at any time. Supported data varies from engine to engine.



59911

ECO Mode Settings


ECO Mode settings allow the adjustment of the fuel economy and RPM display refresh intervals, adjustment of the desired RPM range, and the accuracy of the RPM and trim targets. Defaults are based on the engine model selected in the Engine model selection menu. See **Section 3 - ECO Mode** for additional information.



59912

Cruise/SmartTow Settings


Cruise/SmartTow type settings lets the operator select the source from which VesselView receives speed data—GPS, RPM, or Auto. The default selection is auto. VesselView monitors data from the speed source selection entered during the Setup Wizard.



59913

Trim Settings

Trim settings allows the operator to select which engine's or drive's trim position is displayed on the VesselView screen. When trim is unchecked in the settings menu, the on-screen trim display is replaced with an additional data box.




60216

Show trim checked



60217

Trim displayed on screen



60214

Show trim unchecked




60215

Trim replaced with a data box

Trim Calibration


Trim settings also allows calibration of a drive or engine's trim display range. VesselView shows a graduated scale in the user-selected data box as well as a graduated slider on the bottom of the screen. Trim percentages are represented by the lighter gray marks. Tilt is represented by the darker marks. In the illustration to follow, **a** is trim—0% through 43%, and **b** is tilt—44% through 100%. The white bar on the graph indicates the actual trim position.



59975

- a** - Trim range
- b** - Tilt range—trailing
- c** - Fully trimmed down position


Using the calibration window, trim percentages can be fine-tuned to better display actual limits on-screen in the trim status fields.



59977

- a - Actual trim percentage
- b - Trimmed down percentage
- c - Maximum trim percentage
- d - Maximum tilt percentage

The point at which the trim range and the tilt range meet is the point where trim becomes tilt. This transition percentage point can be adjusted to more accurately reflect the position of the slider bar in the trim scale display.



59976

- a - Trim range
- b - Tilt range—trailing
- c - Digital trim position

EasyLink Settings

Navigation

Navigation through menus can be done by touching, or by using the rotary knob to select the desired tab. The active tab will be highlighted in red. A small arrow in the tab indicates that there are additional menus associated with the setting.

EasyLink settings allow the link gauge connectors on the VesselView harness to be used to transmit data to link gauges at the helm. Four link gauge connections on the VesselView harness are labeled; SYS LINK STBD, SYS LINK PORT, SYS LINK STBDCTR, and SYS LINK PORTCTR.

Section 4 - Setup and Calibrations


The port, port center, starboard center, and starboard link connectors can be chosen to transmit data that comes from sources that are not the same as the link harness label. This can be helpful when similar gauges are located beyond the length of the link gauge female gauge extension harness.



59954

Link gauge connections on the VesselView harness

Engine and transmission data can be selected to display on a compatible link gauge by selecting the harness connection that will be used to transmit the data.




59978

RPM synchronization brings multiple engines to the same RPM level utilizing the SYNC button on the CAN trackpad. If the vessel has a SYNC link gauge, the operator can see the needle move until SYNC is achieved. The default position of the link harness connection is PORT for this gauge, PORT should always remain checked.




60226

SYNC link gauge



59979

During tank setup, information was entered that defined the location, name, and capacity of individual tanks. Link gauge settings allow the operator to select which link harness will transmit data from the tank tab selected. Tank tabs with an arrowhead indicate that tank was defined during tank setup in the vessel settings menu, and can be assigned an EasyLink location.



59981


Preferences Settings

Navigation

Navigation through menus can be done by touching, or by using the rotary knob to select the desired tab. The active tab will be highlighted in red. A small arrow in the tab indicates that there are additional menus associated with the setting.


Buzzer Settings

Buzzer setting allows the user to set the volume level for key touch beeps. The beep is an auditory acknowledgement that a selection has been made.



59925

Alarm beeps can be turned on or off from this tab. All alarms will be displayed on the VesselView screen regardless of the alarm beep status. Alarm beep preferences only apply to alarms that are not driven by the Mercury Guardian system. For example, low fuel level.




59926

Backlight Settings

Backlight preferences can be set with this menu.

- The light level of the display can be changed in ten percent increments from 10 to 100 percent.
- Night mode is available for better low light or dark viewing.
- Network update will display all link gauges and devices connected to the VesselView at the same Level percentage as the operator selects in the Level tab.
- Local gain can only be used to adjust the VesselView display independent of other displays and gauges, even if the Network update box is checked. In some lighting conditions, the VesselView display may be too bright for comfortable viewing, but other displays and gauges may need to maintain their level of brightness. Follow these instructions to apply Local gain to the VesselView display:
 - a. Select Level and choose a percentage of brightness.
 - b. Select Local gain and input the percentage chosen in step **a**, on the keypad, select **OK**.
 - c. Return the Level option to **100%**. The VesselView display will remain dimmed while all networked devices and gauges will maintain their brightness.
 - d. To return the VesselView to full brightness, select Local gain and input **100** and select **OK**.


- e. Select the Level tab and choose any percentage other than 100 and press the rotary knob or touch the percentage, toggle to, or touch the **100%** and the unit will return to 100% brightness.



59927


Scroller Bar Settings

Scroller Bar settings offers an auto-hide delay of five to thirty seconds before it is minimized if no selection is made.



59928


Scroller Bar Item visibility displays the checked items to appear in the scroller bar menu at the bottom of the VesselView screen. Scroller Bar items are preselected based on the engine selection during the Setup Wizard, but any Scroller Bar items can be checked on or off at any time.



59929

Data Boxes Settings

Data Boxes displays up to three items of data on the screen.




59930

The number of data boxes can be increased from one up to three, depending on selections made in the Settings menu. When one data box is displayed it appears in the upper left of the screen. If the option for additional data boxes is grayed out, then all available space is currently being used by the VesselView. To free up space on the screen, use the following directions.


To activate a second data box, enter the Settings menu. Select Vessel>Tabs>Show. Uncheck the Show option to remove the Tabs data from the screen. This area of the screen will be replaced by the second data box.

To activate the third data box, enter the Settings menu. Select Engines>Trim>Show. Uncheck the Show option to remove the Trim data from the screen. This area of the screen will be replaced by the third data box.




60220

Show Tabs unchecked




60224

Two data boxes




60221

Show Trim unchecked



60225

Three data boxes




60222

Data box options shown with trim and tabs unchecked

Popups Settings

Popups allows the operator to select the types of popups that will appear on the screen. Choice of popups include; warnings, Joystick Piloting, and trim information.



59931

The Warnings checkbox allows the operator to have any engine faults displayed full size in the user-selected data area when checked. Unchecked, the fault will appear in the system status field in the lower left of the screen.



60238


Warnings popup unchecked



60239

Warnings popup checked

The Joystick Piloting popup option tells the operator if the engines or drives are trimmed too far up to be effective for maneuvering the boat. This popup only appears once per key cycle. When the operator becomes aware of proper trim procedures before engaging joystick operation, this box can be unchecked.



60234


Trim information popup display duration can be set to two, five, or ten seconds.



59932

Auto-Cycle Interval Settings

Auto-cycle interval determines the duration that data in the user-selected data field is displayed, options are one, five, or ten seconds.



59933


Alarm Settings

Navigation

Navigation through menus can be done by touching, or by using the rotary knob to select the desired tab. The active tab will be highlighted in red. A small arrow in the tab indicates that there are additional menus associated with the setting.

Alarms Settings


Alarms will display the Alarm History list, which records all alarms along with date and time, and Alarm Settings—which can be turned off or on, and have their parameters changed. Show all Helm alarms can be activated from this menu.



59917

Section 4 - Setup and Calibrations

To clear the alarm history, the operator can use an extended time touch anywhere on the screen to bring up an option to clear all alarms. This will delete all recorded alarms.




Alarm History		
Alarm History Started	Raised	12:11 pm 05/12/2015
Alarm History Started	Raised	12:11 pm 05/12/2015
Alarm History Started	Raised	12:11 pm 05/12/2015
Alarm History Started	Raised	3:34 pm 12/19/2012
Alarm History Started	Raised	12:11 pm 05/12/2015
Alarm History Started	Raised	12:11 pm 05/12/2015
Alarm History Started	Raised	1:03 am 07/24/2014
Alarm History Started	Raised	1:03 am 07/24/2014

59918

Alarm history screen

Selecting a data box will open the number pad. Enter the new parameter to specify when an alarm will sound, or be displayed for that item.



Alarm Settings		
No GPS fix	<input type="checkbox"/>	
Shallow water	<input checked="" type="checkbox"/>	6.0 (ft)
Deep water	<input type="checkbox"/>	100.0 (ft)
Water temp rate	<input type="checkbox"/>	9 (°F/min)
Anchor	<input type="checkbox"/>	164 (ft)
Anchor depth	<input checked="" type="checkbox"/>	
Low boat speed	<input type="checkbox"/>	6 (mph)
Speed through water rationality fault	<input type="checkbox"/>	

59919

Alarm Settings screen


Personality File Settings

Navigation

Navigation through menus can be done by touching, or by using the rotary knob to select the desired tab. The active tab will be highlighted in red. A small arrow in the tab indicates that there are additional menus associated with the setting.

Settings

Within the Personality Settings menu, operators can Export and Import a vessel personality. Vessel personalities are files used by boatbuilders and boat owners to set all of the preferences and settings in VesselView, to optimize the systems on board. The micro SD card port is used to transfer files to and from the VesselView. Importable personalities will be detected by VesselView from the micro SD card, and the operator will be able to scroll through the list and select the appropriate personality. To export a personality file, the micro SD card must be inserted into the VesselView.



59920

Export Settings


Exporting the personality file from the VesselView is done by selecting the Export option. A window will appear asking to export the personality. This will create a file which contains all of the settings and preferences of the VesselView. This file can be imported, in the future, to return the VesselView back to the current personality.



59986

Export prompt


The exported file can be found by pressing the GO TO-PAGES button until the Tools screen appears. Open the Files folder icon.



59986

Section 4 - Setup and Calibrations

Select the Memory card icon at the top of the screen. The contents of the memory card will display. Select the Export personality file, personality files have the file extension .sji.



59987

Touching the file, or pressing the rotary knob with the file highlighted will open a screen that will allow the operator to copy, rename the personality file, or to delete the file.



59989

Import Settings

To import a personality file, make sure the SD card is inserted into the VesselView. Select Import and choose from the displayed personalities. All personalities on the SD card must be on the root level, and not in any folders. Importing a personality file can also be done during the Setup Wizard process.



59990

Restore Settings

The restore option can only be used by trained installers to restore OEM settings. A VesselView that is configured by a boatbuilder or dealer contains a file that is specific to the vessel, and can be used to bring the unit back to its configured settings. Contact an authorized dealer, if this option is needed.

Notes:

Section 5 - Warning Alarms

Table of Contents

Warnings—Faults and Alarms.....	92	Depth Alarm.....	94
Fuel Critical Alarm.....	93		

Warnings—Faults and Alarms

All Mercury warnings—faults and alarms will be shown regardless of what screen is displayed at the time of the alarm. When an alarm is activated, the system status field will display the alarm text and warning icon. Faults, along with their descriptive short text, long text, and action text, will be displayed full screen.

- When a fault occurs:
 - a. The system status field will turn red and show the warning icon and text.



52101

- b. Fuel and depth faults will have additional options and will be described in **Fuel Critical Alarm** and **Depth Alarm**.
 - c. A level 3 fault (trim, navigation, ECO, fuel) can be turned off or on by the operator in the Settings menu. By default it is turned on. If the fault is turned off in the Settings menu, the faults will only show in the system status field.
 - d. All level 4 (Guardian) faults will always be displayed regardless of what is selected in the Settings menu.
 - e. If the fault is related to emissions control, the engine icon will be displayed in the system status field.
- When the operator selects a fault in the user-selected data area:
 - a. The fault title with the warning icon will be displayed at the top.
 - b. Short text fault description and the fault location (engine) will be displayed below the title.
 - c. When more than one fault exists, use the rotary knob to navigate to each fault and press the rotary knob to access the fault.



- a - Warning icon with fault title
- b - Short descriptive text
- c - Engine fault location
- d - Action text
- e - Additional fault information


60627

Additional information, or long text about the current fault can be viewed by selecting the + box in the lower left corner of the user-selected data area.



60628

If additional descriptive text is available, it will display in the fault window. Additional information can be text or a specific universal fault code. A universal fault code can be helpful to the operator when communication with a dealer or repair facility.



60630

Universal fault code

Selecting acknowledge will remove the fault warning from the user-selected data area, and the system status tray will contain the warning icon and text on a red background, as a reminder to service the engine soon.




60629

Fuel Critical Alarm

The fuel alarm is managed by VesselView, not by the engine ECM/PCM.

- Notification properties and fuel level alarms can be set in the Settings menu.



60356

Section 5 - Warning Alarms

- The warning will replace the current user-selected data area and the system status field will change to a red field.




- Pressing the rotary knob will minimize the fuel level alarm. The fault will still be displayed in system status field.

Depth Alarm

The depth alarm is managed by VesselView, not by the engine ECM/PCM.

- Display notification properties and depth warning levels can be set in the Settings menu.



- The warning will replace the current user-selected data area and the system status field will change to a red field.



- Pressing the rotary knob will minimize the depth alarm. The fault will still be displayed in system status field.