



- (7) ENGINE POSITIONING:
- A) THE STERN DRIVE AND ENGINE CENTERLINES MUST BE PARALLEL.
 - B) THE ANGLE BETWEEN THE DRIVE SHAFT AND BOTH THE STERN DRIVE AND ENGINE CENTERLINES MUST BE WITHIN THE RANGE INDICATED. WHEN POSITIONED AS SUCH, THE ENGINE CENTERLINE WILL BE 7/16 (11MM) TO 1-3/8 (35MM) ABOVE (OR BELOW) THE STERN DRIVE CENTERLINE. REFER TO INSTALLATION INSTRUCTIONS.
 - C) WHEN VIEWED FROM ABOVE, THE STERN DRIVE, DRIVE SHAFT, AND ENGINE CENTERLINES MUST BE IN LINE.

UNIT OF MEASURE in. (mm)	SCALE APPROX. 1" = 1" 25.4mm = 304mm
-----------------------------	--