


- NOTES:**
- (1) Dimensions Require a 3/4 in. (19mm) Minimum Clearance Due to Engine Mount Deflection. Riser Height to Mount the Exhaust Elbow and the Wateline of the Boat at Maximum Rated Load.
 - (2) Select the Appropriate Exhaust Riser Height to Match the Boat's (SCM) Exhaust Wateline of the Boat at Maximum Rated Load.
 - (3) Exhaust Outlets Must Be Above Wateline of Boat at Maximum Rated Load, and Exhaust Flappers are Recommended Over Each Exhaust Outlet.
 - (4) Dimensions Apply to Point of Intersection of Output Shaft Centerline and Output Flange Face.
 - (5) For Correct Cabin/Water Heater Installation Refer to Installation Manual.
 - (6) For Recommended Propshaft Cooling Water Connection Refer to Installation Manual.
 - (7) See Installation Manual or Instruction Sheet 90-861069-1 for Exhaust Resonator Installation.

MIE 8.2L MPI BLUEWATER WITH VEELVET DRIVE 5000A) DOWN-ANGLE TRANSMISSION

MIE 8.2L MPI BLUEWATER WITH (HURTH 630A) DOWN-ANGLE TRANSMISSION

MERCURUISER ACCESSORIES:
(1) Hot Water Heater Kit: 22-72932A3



SCALE APPROX.
1" = 1"
25.4 mm = 304 mm

UNIT OF MEASURE
in. (mm)